

Batching System Control

Created: 03/02/2018

Last Revised: 03/16/2018

Authors: Alex Cutsinger, Daniel Hinkle, and Korbyn Thompson

Electrical Engineers

University of Arkansas, PLC Class

Email: dhinkl01@g.uafs.edu, kthomp10@g.uafs.edu, acutsi02@g.uafs.edu



Attachments:

Functional Requirements; Design Details; PLC Program

Table of Contents

| | |
|---------------------------------|---|
| ● Scope of Work | 2 |
| ● Functional Requirements | 3 |
| ● Enhancements | 4 |
| ● Concerns | 4 |
| ● Implementation Design Details | 4 |
| ● PLC Code Listing | 6 |
| ● Error Code Descriptions | 6 |




Figure 1: Logix Pro Batch Simulator

Scope of Work:

Provide software and documentation for implementation of PLC based control of the pumps, heating and mixing of the vat in the factory. The facility where this application is to be installed is essentially identical to that which comprises the “Batch Simulator” simulation model in the LogixPro software application. The PLC to be used is identical to that provided by LogixPro. The automation requirement is to pour in the first ingredient from pump one, pour in the second ingredient from pump two, and mix and heat them before pumping the mixture out through pump three when the user hits the “Start” push button. The amount of gallons for ingredients one and two are determined by user input, and whether or not to heat the mixture is determined by the user as well. When the user hits the “Stop” push button, the batching system will go into “Idle”

mode where the pumps will stop pouring ingredients into the tank, and mixing and heating will discontinue. However, when the “Start” push button is pressed in idle mode, the job will continue as normal. When the “Stop” push button is held for three seconds, the job is cancelled. When this occurs all pumping, mixing, and heating will cease and the tank will automatically drain. In addition, there are three different variations to this entire process, two formulas and a drain. When the selector switch is on “A”, the batching system will produce Formula A, whose ingredient amounts, mixing time, and heating time are determined by the user using the BCD input. When the selector switch is on “B”, the batching system will produce Formula B. Formula B’s information is determined by the BCD input as well. Finally, when the selector switch is on “C” the batching system will drain the tank and do nothing else.

Functional Requirements:

This application comprises a PLC based control system that provides the following functionality:

- 1) The LogixPro “Batch Simulator” simulation model is being controlled using the LogixPro PLC.
- 2) The batching system must be able to run two separate batches independently, based on the selector switch.
- 3) While the program is in “Stop” mode users may input formula data for formulas A and B.
- 4) While the program is running and the “Stop” button is pressed the program will go into idle mode. No formula entry should be done here.
- 5) While the program is running and the “Stop” button is held for three seconds the program will go into “Stop” mode. The tank will automatically drain, and formula entry may be performed.

6) Before filling the tank, the “Run” lamp will blink for five seconds to alert users that the equipment will soon be in use.

7) For more in depth descriptions of the requirements, refer to the attached document, “AutoBatch-FunctionalRqmnts-2018.docx”.

Enhancements:

- The job requirements did not address the possibility that the operator of the system might input a total amount that is greater than the physical capacity of the tank. This was fixed by not allowing the user to start a batch if the total value exceeds the capacity of the tank and an E001 will be displayed to signify an error.
- To avoid an inefficient process the batch was not allowed to begin mixing before the tank contained 40 gallons of fluid.

Concerns:

- If the operator tries to adjust the “active formula” while the batch is running the behavior of the machine will become unpredictable.

Implementation Design Details:

I/O Devices and Wiring Summary

| Item | PLC I/O Point | Function Label | Physical Device Label | Comments |
|------|---------------|----------------|-----------------------|------------------------------|
| 1 | I:1/00 | Start PB | PB-2 | NO, momentary push to start. |

| | | | | |
|----|--------|-------------------|-------|--|
| 2 | I:1/01 | Stop PB | PB-3 | NC, momentary push to stop. |
| 3 | I:1/02 | Thermostat | TT1 | Heater interlock |
| 4 | I:1/03 | LO-LEVEL | LI2 | Tank empty interlock |
| 5 | I:1/04 | HI-LEVEL | LI1 | Tank overflow interlock |
| 6 | I:1/05 | Flowmeter 1 | FM1 | Ingredient 1 measurement |
| 7 | I:1/06 | Flowmeter 2 | FM2 | Ingredient 2 measurement |
| 8 | I:1/07 | Flowmeter 3 | FM3 | Drain measurement |
| 9 | I:1/08 | Enter PB | PB-1 | Stores the entered data to the selected formula when in formula entry mode |
| 10 | I:1/09 | Formula A | SS1-A | Selects to run a batch of Formula A |
| 11 | I:1/10 | Formula B | SS1-B | Selects to run a batch of Formula B |
| 12 | I:1/11 | Clear Tank | SS1-C | Selects tank empty mode |
| 13 | I:3 | Formula/Job input | TWS | |
| 14 | O:2/0 | Mixer | MXR | Mixer motor enable |
| 15 | O:2/1 | Pump 1 | PMP-1 | Ingredient 1 pump enable |
| 16 | O:2/2 | Pump 2 | PMP-2 | Ingredient 2 pump enable |
| 17 | O:2/3 | Pump 3 | PMP-3 | Drain enable |

| | | | | |
|----|-------|-------------|-----|--|
| 18 | O:2/4 | Heater | HTR | Heater enable |
| 19 | O:2/5 | RUN | L1 | Run indicator light |
| 20 | O:2/6 | IDLE | L2 | Idle indicator light |
| 21 | O:2/7 | FULL | L3 | Full indicator light |
| 22 | O:4 | BCD display | BCD | Displays the entered formula data when in formula entry mode, displays tank fill level while running, and displays error messages for 3 seconds as they occur. |

PLC Code Listing:

See attached PLC program file listing copy entitled, “*BatchByCHT*.rsl”.

Error Code Descriptions:

| | | |
|------|--|---|
| E001 | | Stored formulas will overflow the tank. |
|------|--|---|